OpenCV in Python

Dr. Zoran Duric

Department of Computer Science George Mason University

Office: Nguyen Engineering Building 4443

Email: zduric@cs.gmu.edu

OpenCV Resources

- 1. OpenCV documentation etc.
- 2. OpenCV API Reference
- 3. OpenCV Safari Books Free for GMU students
- 4. OpenCV Computer Vision with Python A good source for installation in various OS, code examples, etc.
- Programming Computer Vision with Python Not OpenCV, but a lot of examples

Read an Image

Use the function cv2.imread() to read an image. First argument is the image name. The image should be in the working directory or a full path of image should be given. Second argument is a flag which specifies the way image should be read.

- cv2.IMREAD_COLOR : Loads a color image.
- cv2.IMREAD_GRAYSCALE: Loads image in grayscale mode
- cv2.IMREAD_UNCHANGED: Loads image as such including alpha channel

Note Instead of these three flags, you can simply pass integers 1, 0 or -1 respectively.

See the code below:

```
import numpy as np
import cv2
# Load an color image in grayscale
img = cv2.imread('messi.jpg',0)
```

Display an Image

Use the function cv2.imshow() to display an image in a window. The window automatically fits to the image size.

First argument is a window name which is a string. Second argument is our image. You can create as many windows as you wish, but with different window names.

```
cv2.namedWindow('image', cv2.WINDOW_NORMAL) # not required
cv2.imshow('image',img)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

cv2.waitKey() is a keyboard binding function. Its argument is the time in milliseconds. 0 – wait indefinitely cv2.destroyAllWindows() simply destroys all the windows we created. To destroy any specific window, use the function cv2.destroyWindow() where you pass the exact window name.

Write an Image

Use the function cv2.imwrite() to save an image. First argument is the file name, second argument is the image you want to save.

A simple program using all functions:

In addition, you can use Matplotlib to display images.

Capture Video from Camera

```
import numpy as np
import cv2
cap = cv2.VideoCapture(0)
while(True):
    # Capture frame-by-frame
    ret, frame = cap.read()
    # Our operations on the frame come here
    gray = cv2.cvtColor(frame, cv2.COLOR\_BGR2GRAY)
    # Display the resulting frame
    cv2.imshow('frame',gray)
    if cv2.waitKey(1) \& 0xFF == ord('q'):
        break
# When everything done, release the capture
cap.release()
cv2.destroyAllWindows()
```

Playing Video from File

It is same as capturing from Camera, just change camera index with video file name. Also while displaying the frame, use appropriate time for cv2.waitKey(). 25 milliseconds will be OK in normal cases.

```
import numpy as np
import cv2
cap = cv2.VideoCapture('/Users/zduric/Desktop/008a014s00R.dv')
while(cap.isOpened()):
    ret, frame = cap.read()
    gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
    cv2.imshow('frame',gray)
    if cv2.waitKey(25) \& 0xFF == ord('q'):
        break
cap.release()
cv2.destroyAllWindows()
```

Saving a Video

```
import numpy as np
import cv2
cap = cv2.VideoCapture(0)
size = (int(cap.get(cv2.cv.CV_CAP_PROP_FRAME_WIDTH)),
     int(cap.get(cv2.cv.CV_CAP_PROP_FRAME_HEIGHT)))
# out = cv2.VideoWriter('output.avi',cv2.cv.CV_FOURCC('I','Y','U','V'), 30, size,True)
out = cv2.VideoWriter('output.avi',cv2.cv.CV_FOURCC('X','V','I','D'), 30, size,True)
while(cap.isOpened()):
     ret, frame = cap.read()
    if ret:
         out.write(frame)
         cv2.imshow('frame',frame)
         if cv2.waitKey(1) \& 0xFF == ord('q'):
              break
     else:
         break
cap.release()
out.release()
```